



TYPE 9M6 BOTTLES

CLOSURE INSTRUCTIONS AND RECOMMENDED TORQUE

1/ ALUMINUM BOTTLE

2/ LDPE PLUG

3/ PP CAP WITH ALPE/PEE LINER

After filling, insert the sealing plug to full depth by pushing it down, screw the cap to the following recommended torque: Between 9 and 13 Inch per lbs.